




**Enerdrive**  
DRIVING YOUR ENERGY NEEDS

**In Vehicle & Marine Applications**  
For In Vehicle & Marine Installations.  
i.e. Motorhomes, 4WD's, Trucks & Boats

**Please NOTE:**

Vehicles with a Smart alternator, the Negative cable must be connected to the vehicle Side of the Battery Sense Module.

Non Regulated Fix or Folding Solar Panels Max 45VOC  
See Manual for input specifications



**DC to DC Battery Charger**



(Optional) Ignition sense wire required for smart alternator vehicles




Fuse 1Amp


See Owners Manual for cable size

Ignition Link 1.5mm<sup>2</sup>

(Optional) Solar Isolator




**DC Loads**



See Owners Manual for fuse rating

See Owners Manual for cable size



**12v House Battery**

Enerdrive has provided this drawing as a guide only and installers must ensure the system is installed to the local requirements for fuse protection and wire sizing (see Manual). If you have any questions please call; Enerdrive on 07 3390 6900