

Appendix A1 LEAD ACID MODE


VERSION: REV. 1.0

DC2DC+ ePOWER charger

Charger configuration is a simple step by step process as shown below.

For Tech Support call Enerdrive on **1300 851 535**

NOTE: The current setting below is based on the EN3DC40+ battery charger.



NOTE: At any function setting, pressing the MENU button will exit the function mode.

WARNING: FIRE HAZARD

When choosing the battery type and setting the charging parameter, please consult the battery manufacturer on all the voltage and current settings. Using the wrong setting to charge a battery may overcharge, damage the battery and may cause a fire.